



| Item | Part No. | Description |
|------|------------|-------------------------------------|
| 1 | HHB1290.S | HEX HEAD BOLT M12x90mm SINGLE |
| 2 | SPC1000.02 | WASHER |
| 3 | SPC1000.03 | NUT |
| 4 | SPC1000.04 | PIN |
| 5 | SPC1000.05 | FRONT WHEEL 34X17 |
| 6 | SPC1000.06 | WHEEL AXLE |
| 7 | SPC1000.07 | LEG |
| 8 | SPC2000.08 | END PLUG |
| 9 | SPC1000.09 | PIN (inc 10 & 11) |
| 12 | SPC1000.12 | NUT |
| 13 | SPC2000.13 | WASHER |
| 14 | SPC2000.14 | WHEEL, FIXED CASTOR (125x11x32x160) |
| 15 | SPC2000.15 | WASHER |
| 16 | SPC2000.16 | COVER |
| 17 | SPC2000.17 | SPACER |
| 18 | SPC2000.18 | WASHER |
| 19 | SPC2000.19 | SPRING WASHER |
| 20 | SPC2000.20 | BOLT 18X30 |
| 22 | SPC1000.22 | WHEEL, FIXED (74x12x25) |
| 23 | SPC2000.23 | HANDLE GRIP |
| 24 | SPC2000.24 | HANDLE |

| Item | Part No. | Description |
|------|------------|--|
| 25 | SPC1000.25 | SNAP RING |
| 26 | SPC1000.26 | PIN |
| 27 | SPC1000.27 | RAM SEAT |
| 28 | SPC1000.28 | RAM ASSEMBLY |
| 29 | SPC1000.29 | SPACER |
| 30 | SPC1000.30 | BOLT |
| 31 | SPC1000.31 | BASE |
| 32 | SPC1000.32 | NUT |
| 33 | SPC1000.33 | BOOM |
| 34 | SPC1000.34 | PIN |
| 35 | SPC1000.35 | SPRING PIN |
| 36 | SPC1000.36 | SNAP RING |
| 37 | SPC1000.37 | PIN |
| 38 | SPC1000.38 | BOOM EXTENSION |
| 39 | SPC1000.39 | PIN |
| 40 | SPC2000.40 | PIN |
| 41 | SPC2000.41 | CASTLE NUT |
| 42 | SPC2000.42 | HOOK SEAT |
| 43 | SPC2000.43 | HOOK ASSEMBLY (inc 44/45/46/47/48/49/50) |
| 51 | SPC1000.51 | BEARING |

NOTE: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice.

IMPORTANT: No liability is accepted for incorrect use of product.

WARRANTY: Guarantee is 12 months from purchase date, proof of which will be required for any claim.