The factory where equipment is stored is responsible for making entries in the Operation Sheet. The Operation Sheet should be completed before the equipment is first put into operation. All information concerning protective equipment (name, serial number, date of purchase and date of putting into operation, user name, information concerning repairs and inspections and withdrawal from use) must be included in the Operation Sheet of a particular device.

> The sheet is completed by the person responsible for safety equipment in a given place of work. Equipment without a properly completed Operation Sheet cannot be used.

OPER	RATION SHEET
DEVICE NAME MODEL	REFERENCE NUMBER
SERIAL NUMBER	DATE OF MANUFACTURE
USER NAME	
DATE OF PURCHASE	DATE OF PUTTING INTO OPERATION

	TECHNICAL INSPECTIONS							
	DATE OF INSPECTION	REASONS FOR INSPECTION OR REPAIR	NOTED DEFECTS, PERFORMED REPAIRS, OTHER NOTES	DATE OF SUBSEQUENT INSPECTION	SIGNATURE OF THE PERSON RESPONSIBLE			
1								
2								
3								
4								

European Certificate was made in CETE APAVE SUDEUROPE, BP 193, 13322 Marseille, France 0082 Tacklestore Ltd, Unit 23 Atlantic Road, Avonbridge Trading Estate, Avonmouth, Bristol, BS11 9QD, England tel. 0044 1179 381600, fax 0044 1179 381 602, www.fall-protection.uk.com



# **Operational Instructions**

Carefully read the instruction before using the device


€ 0082 Ref.: AF 500 xx EN 358:2000





The AF 500 work positioning lanyard is an element of personal protective equipment and serves as a supplement to protective equipment against falls from a height while working on pillars. trees, building structures etc.

This device is indispensable in all situations which require work positioning (support). This device is manufactured in accordance with the standard EN 358 Personal protective equipment against falls from a height. Belts for work, positioning and restraints and work positioning lanyards.



## ATTENTION!

The AF 500 lanyard can be equipped only with certified snap hooks according to EN 362.

## **WORKING LIFE**

The AF 500 lanyard can be used for a maximum period of 5 years from the date of first putting it into use.

After a period of 5 years, the lanyard is to be withdrawn from use and physically destroyed, thus preventing it from an unintentional reuse.

Withdrawal from use should be performed by the person responsible for safety equipment in a given place of work.

# **DESCRIPTION OF MARKING**

device type	_WORK POSITIONING LANYARD	
reference number*	_AF 500 xx	
lanyard serial number	*) xx device length design —Serial number: <b>0000002</b> for example: xx = 05 - 0	
month and year of manufacture	—Date of manufacture: <b>09.2007</b>	
number and year of issuing an European standard applicable for the lanyard	EN 358:2000	
note: study the instruction before use	$\mathbf{\hat{i}}$	
The CE mark and number of the notified body responsible for performing the manufacturing process inspection (art. 11)		
manufacturer or distributor marking	G-Force	


#### **PUTTING ON THE LANYARD**

- 1. Fasten one of the lanyard snap hooks on the right (or left for left-handed people) belt fastening buckle for work positioning in accordance with EN 358 fig. 1.
- 2. Put the lanyard around a structure and fasten the snap hook to the second (free) belt fastening buckle fig. 2 or fasten the snap hook to a permanent anchor point located above. If the belt has a front fastening buckle (according to EN 813), then one snap hook may be attached to this buckle and the other to the permanent anchor point. The tension and length of the lanyard must limit a free fall path to a maximum of 0.5m.

**ATTENTION:** Check if connections between each separate fastening element are stable. Snap hooks must be closed and protected with a mechanism which prevents them from accidental opening.

## **ATTENTION**

The AF 500 work positioning lanyard is not a safeguard against falling from height and cannot be used as such. Workers using the AF 500 lanyard while working at height must be additionally protected with personal protective equipment against falls from a height, according to EN 363.



IT IS FORBIDDEN TO USE THE AF 500 LANYARD FOR APPLICATIONS OTHER THAN THOSE SPECIFIED IN THE OPERATIONAL INSTRUCTION

#### FUNDAMENTAL RULES FOR USING PERSONAL PROTECTIVE EQUIPMENT

- personal protective equipment should be used only by people trained in operating it.
- personal protective equipment cannot be used by people whose health condition may influence their safety during everyday use or emergency procedures.
- there must be a rescue operation plan which can be used whenever needed.
- it is forbidden to perform any modifications of the equipment without the written consent of the manufacturer.
- . any repairs of the equipment may be performed only by its manufacturer or an authorised representative of the manufacturer.
- personal protective equipment must be used in conformity with its operational purpose.
- personal protective equipment is considered personal equipment and should be used by a single person only.
- make sure that all elements of the equipment that constitute the fall prevention system are properly mated prior to use. Perform periodical inspections of connections and mating of equipment in order to avoid unintentional loosening or disconnecting.
- it is forbidden to use protective equipment if one of its elements is hampered by another during operation.
- all parts of the fall prevention equipment must be in accordance with appropriate regulations and equipment operational instructions and binding standards:
  - EN 361 for full body harnesses
  - EN 353-1, EN 353-2, EN 354, EN 355, EN 360, EN 362 for fall prevention systems
  - EN 795 for equipment anchor points (permanent anchor points)
  - EN 358 for work positioning systems

- carry out a careful inspection of personal protective equipment prior to each separate use in order to check its condition and operation.
   Inspections must be performed by the user.
- such inspections should check all equipment elements with particular attention paid to: any defects, excessive wear, corrosion, points of tearing, cuts and improper operation. Particular attention must also be paid to each individual device:
  - full body harnesses and work positioning belts: buckles, adjustment elements, fastening points (snap hooks), slings, seams, loops;
  - energy absorbers: hitch loops, slings, seams, body and connectors;
  - lanyards and textile guides: lanyards, thimbles, connectors, adjustment elements, plaits:
  - lanyards and steel guides: lanyards, wires, clamps, loops, thimbles, connectors, adjustment elements;
  - retractable type fall arresters: lanyards or slings, correct operation of winding mechanism and locking mechanism, body, shockabsorber, connectors;
  - guided type fall arresters: device body and its correct movement along the guide, operation of locking mechanism, rollers, bolts and rivets, connectors, safety shock-absorber;
  - connectors (snap hooks): load-bearing body, riveting, main catch, operation of locking mechanism.
- personal protective equipment must be withdrawn from use and undergo a complete periodical inspection at least once a year (after 12
  months of use). Periodical inspection must be carried out by a qualified person responsible for periodical inspections of safety equipment
  in a given place of work. Periodical inspections must be also carried out by the equipment manufacturer or an authorised representative
  of the manufacturer. Such an inspection should check all equipment elements with particular attention paid to: any defects, excessive
  wear, corrosion, points of tearing, cuts and improper operation (see the previous point).
- If protective equipment has a complex structure, for example retractable type fall arresters, periodical inspections should be carried out
  only by the equipment manufacturer or its authorised representative. The date of the subsequent inspection shall be specified after the
  periodical inspection has been completed.
- regular periodical inspections are essential in terms of equipment condition and safety of users only fully operational equipment is able to provide safety.
- make sure that all labels on protective equipment (elements of this equipment) are legible while performing a periodical inspection.
- all information concerning protective equipment (name, serial number, date of purchase and date of first operation, user name, information concerning repairs and inspections and withdrawal from use) must be included in the Operation Sheet for a particular device. The factory where equipment is stored is responsible for making entries in the Operation Sheet. The Sheet should be completed by the person responsible for safety equipment in a given place of work. Equipment without a properly completed Operation Sheet cannot be used.
- if equipment is exported to other countries, the provider must equip it with operational and maintenance instructions as well as information
  concerning periodical inspections and repairs in the language of the country where the equipment is going to be used.
- personal protective equipment must be immediately withdrawn from use if there are any doubts concerning its condition or operational
  correctness. Equipment can be reused after it has undergone a complete inspection carried out by the manufacturer and written
  authorisation for reuse has been issued.
- if personal protective equipment was used to prevent a fall, it must be withdrawn from use and physically destroyed.
- a full body harness in accordance with EN 361 is the only accepted device for keeping a body in the personal protective equipment
  against falls from a height.
- fall arresting systems can be connected only to full body harness fastening points (buckles, loops) marked with the capital letter "A".
- anchoring points (equipment) of fall preventive systems should have stable structure and their position should reduce the possibility of
  falling and minimise the range of a free fall. The equipment anchoring point should be located above the users work position. The shape
  and structure of the equipment anchoring point must provide a durable connection and prevent any random disconnection. It is
  recommended to use certified and marked equipment anchoring points in accordance with EN 795.
- it is required to inspect the free space under the work-place on which individual fall preventive equipment is going to be used in order to
  eliminate the possibility of hitting any objects or lower planes while stopping a fall. The amount of free space under the work-place is
  specified in the operational instructions of the protective equipment to be used.
- while using the device, pay special attention to hazardous situations which may influence equipment operation and the safety of users, including in particular:
  - kinking and rubbing of lanyards on sharp edges;
  - pendulum falls;
  - current conductivity;
  - any damage such as cuts, wear, corrosion;
  - extreme temperature impact;
  - negative impact of weather conditions;
  - impact of aggressive substances, chemicals, solvents, acids.
- personal protective equipment must be transported in packaging which protects it against damage or water, for example in bags made of
  impregnated material or in steel or plastic containers or boxes.
- personal protective equipment must be cleaned and disinfected in order to avoid damaging the material (raw material) it is made of. Clean
  textile materials (slings, lanyards) with cleaning agents intended for soft materials. It can be cleaned manually or washed in machines. It
  must be carefully rinsed. Plastic elements can only be cleaned with water. Equipment which becomes wet during cleaning or while in
  operation must be carefully dried in natural conditions, away from heat sources. Metal parts and mechanisms (springs, hinges, catches
  etc.) can be periodically greased in order to improve their operation.
- personal protective equipment should be stored in loose packaging in well-ventilated dry rooms and protected against the impact of light UV radiation, dust, sharp objects, extreme temperatures and caustic substances.