



A Inspectic	n torm								
inspection every 12 months and after	r each use, PPE should regularly under any exceptional event in the life of the pr acted with the manufacturer's Instruction COM.	roduct.	y a competent person. Petzl reco	ommends	an				
PROFESSIONAL HARNESSES			PPE information						
Surname Address Identifier			Model Serial number Year of manufacture Date of purchase Date of first use Manufacturer: Petzl, Zl Cidex 105A - 38920 Crolles - France						
Good condition (G)	Contraction (TM)	To repair (TR)	Do not use, retire (f	R)			N/A applicable		
1. Known product history Usage conditions or exceptional event du or fail arrest, use or storage at extreme ter outside manufacturer's facilities) :									
				\oslash	Q,	X	⊗• 🖥	N/A	
 3. Checking the condition of the st • Check for cuts, swelling, damage and w linkage and shoulder straps, if present. Be 	een exceeded. here are no modifications or missing parts. traps vear due to use, to heat, and to contact with s sure to check the areas hidden by the buck ng on both sides. Look for any threads that a	kles.							
 4. Checking the attachment points Check the condition of the metal attachment points (marks, cracks, wear, deformation, corrosion). Check the condition of the textile attachment points (cuts, wear, tears). Check the condition of the plastic attachment points (cuts, wear, tears). On the multi-standard NAVAHO and AVAO harnesses, check the fall arrest indicator. The indicator shows red if the dorsal attachment point sustains a shock load greater than 400 daN. 									
	CK adjustment buckles (marks, cracks, wear ment buckles (marks, cracks, wear, deforma aded, with no twists.								
6. Checking the condition of the comfort parts • Check the condition of the waist, leg and shoulder foams (cuts, wear, tears). • Check the condition of the leg loop elastics (cuts, wear, tears). • Check the condition of the leg loop elastics (cuts, wear, tears). • Check the condition of the equipment loops (cuts, wear, tears).									
 For connector inspection, see the inspection. Gated attachment point: verify that the s If the harness features a chest/seat harn 	hest/seat harness connector (if any) ction form for your connector model at Petzl screws on the gated attachment point are pr hess connector, make sure that it is present. nodel and that it is correctly attached to the l	resent and properly tightened.							
8. Checking the condition of the CFor rope clamp inspection, see the inspection.	ROLL rope clamp (if any) ection form for your rope clamp model at Pe	etzl.com.							
frayed strands, fuzzy areas, or signs of ch	ment bridge (cuts, wear, tears). For attach		•						
 10. Special case: NEWTON HI-VIZ • On the HI-VIZ models, check the conditional statement of the second statem	ion of the HI-VIZ vest and of the reflective ba	ands (cuts, wear, fading).							
Comments (detail here any defect	is found on the product and accompl	lished tasks)							

VER	D)	ют
	- 4	

Product **fit** to remain in service Product **unfit** to remain in service Inspected by Company

Date

Next inspection date

PPE INSPECTION - Inspection form - PROFESSIONAL HARNESSES (151019)